



Hand Pumps

Double Acting for Single Acting Cylinder – Tankless (Wall Mount)	3.02
Double Acting for Single Acting Cylinder – Tank Mounting	3.03
Double Acting for Double Acting Cylinder – Tank Mounting	3.03
Steel TanksSteel Tanks	3.04
Spare Parts	3.05




[3.01]






Double Acting for Single Acting Cylinder – Tankless (Wall Mount)



Order Code	Description	Displacement (cm³)	Max. Pressure (bar)	pPorts	Release Knob
PRBC-4102883	PRBC20M	20	350	P = G 3/8 (Male)	Yes
PRBC-4104206	PRBC20EM	20	350	T = G 1/2 (Female)	No

Note:

- Displacement is per cycle. One cycle is extend and retract of the handle.
- All Hand Pumps are supplied with a Bellows over piston shaft & a Handle.
- PRBC Hand Pumps do not have a Relief Valve.








Double Acting for Single Acting Cylinder – Tank Mounting






Order Code	Description	Displacement (cm³)	Max. Pressure (bar)	Outlet Port
PRB-4092997	PRB12RM	12	380	
PRB-4092986	PRB25RM	25	350	G 3/8 (Male)
PRB-4105075	PRB45RM	45	280	

Double Acting for Double Acting Cylinder – Tank Mounting






Order Code	Description	Displacement (cm³)	Max. Pressure (bar)	Outlet Ports	
PRBD-4093000	PRBD12RM	12	380		
PRBD-4092990	PRBD25RM	25	350	G 3/8 (Male)	
PRBD-4105087	PRBD45RM	45	280		

Note:

- Displacement is per cycle. One cycle is extend and retract of the handle.
- Relief Valve factory set to Max. Pressure.
- All Hand Pumps are supplied with an Adjustable Relief Valve, Bellows over piston shaft, Handle,
 Suction Filter, Suction Tube, Rubber Gasket, SHCS & Spring Washers for mounting to our tank or yours.
- Prices do not include a tank. They are sold separately. Refer to Page 3.04.
- RP Tanks are supplied with the correct length suction tube.
 Do not use the one supplied with the hand pump. Fit the serrated end of hose inside the suction strainer.
- When using RP Tanks hand pump can only be mounted with the handle horizontal.
- Hand Pumps can be mounted to your tank with the handle vertical. Ensure you use sealed nuts or thread sealant and take care not to kink and block the Suction Tube.








Steel Tanks





Order Code	Dogovintion	Usable Capacity	Dimensions				
Order Code	Description		а	b	С	d	е
RP-4112720	RP1G	1 litre			120		
RP-4112721	RP2G	2 litres	100	170	170	120	173
RP-4112745	RP3G	3 litres			220		
RP-4112733	RP5G	5 litres			200		
RP-4112734	RP7G	7 litres	175	175	290	195	178
RP-4112735	RP10G	10 litres			380		

Note: Tanks are 2 mm thick steel, welded construction, painted RAL9005 black, supplied with breather, drain plug and suction tube.





Spare Parts



Order Code	Description		
4093434	Handle PRB / PRBC / PRBD – 27 mm Ø x 550 mm		
4093123	Relief Valve PRB**RM / PRBD**RM		
4093934	Lowering Valve PRB12 / PRB25 / PRBC20		
4105136	Lowering Valve PRB45		
7569217	Breather Hand Pump RP* Tank - M22 x 1.5 (Suits Old Order Code)		
4109429	Suction Tube & Filter PRB / PRBD (Tube – 300 mm long. Suits RP10, Cut tube to length for other sizes)		
4092941	PVC Bellows PRB / PRBC / PRBD		
4110111	Seal Kit - PRB12R		
4110114	Seal Kit - PRB25R		
4110115	Seal Kit - PRB45R		
4115864	Seal Kit - PRBC20		
4110112	Seal Kit - PRBD12R		
4107504	Seal Kit - PRBD25R		
4110116	Seal Kit - PRBD45R		